




HOWO TRUCK SPARE PARTS

发动机配件系列 Engine Part Series




发动机总成 Engine Assembly



发动机总成 Engine Assembly



水泵 Water Pump



气缸体 Cylinder Block



曲轴总成 Crankshaft Assembly



重汽四配套
SINOTRUK Four Matching

HOWO TRUCK SPARE PARTS



发动机配件系列 Engine Part Series



重汽主机活塞环
SINOTRUK Main Piston Ring



湖南江滨活塞
Hunan Jiangbin Piston



重汽主机气缸套
SINOTRUK Main Cylinder Liner



涡轮增压器
Turbocharger



飞轮
Flywheel



飞轮壳
Flywheel Shell



齿轮室
Gear Room



连杆
Link



气门推杆
Valve Push Rod



气门弹簧
Valve Spring



气门摇臂
Valve Rocker



气门油封
Valve Seal



连杆螺栓
Connecting Rod Bolt



气缸盖
Cylinder Head



油底壳
Oil Sump



油气分离器
Oil And Gas Separator



HOWO TRUCK SPARE PARTS

发动机配件系列 Engine Part Series



汽缸垫
Cylinder Pad



曲轴止推片
Crankshaft Thrust Piece



连杆瓦
Connecting Rod



机油泵
Oil Pump



中间齿轮
Intermediate Gear



喷油泵齿轮
Fuel Injection Pump Gear



空压机齿轮
Air Compressor Gear



凸轮轴齿轮
Camshaft Gear



输油泵
Pump



冷却器盖
Cooler Cover



机油冷却器芯
Oil Cooler Core



气缸盖罩
Cylinder Head Cover



风扇叶
Fan Leaf



排气歧管
Exhaust Manifold



进气管
Intake Pipe



出水管
Outlet Pipe

HOWO TRUCK SPARE PARTS



发动机配件系列 Engine Part Series



双缸空压机
Double Cylinder Air Compressor



起动机
Starter



气缸套
Cylinder Liner



活塞
Piston



发电机支架
Generator Bracket



喷油器总成
Fuel Injection Assembly



进气管垫
Intake Pipe Pad



排气管垫
Exhaust Pipe Pad



增压器垫
Supercharger Pad



气缸罩垫
Cylinder Head Gasket



凸轮轴衬套
Camshaft Bushing



气门座圈
Valve Seat



发动机前支撑
Engine Front Support



发动机后支撑
Engine Rear Support



空气滤芯
Air Filter




机油滤芯
Oil Filter



HOWO TRUCK SPARE PARTS

曼发动机配件系列 MAN Engine Parts Series

				
200V05504-0107 Oil Filter	VG1560080011 Rotary Fuel Meticulous Filter Assembly	WG9925550202/1 Filter	WG9725190103 Safety Filter Assembly	201V12503-0061 Fuel Filter Core
				
200V77970-7028 Refrigeration Compressor	080V01510-0280 Front Oil Seal	AZ1034121000 DCU	AZ1034121018 DCU	VG1246020005 Shock Absorber
				
200V05840-0128 Oil Sump Block	200V27120-7038 Speed Sensor	200V19101-0307 Generator Bracket	201V01510-0283 Crankshaft Rear Oil Seal	派克滤芯总成 Parker Filter Assembly
				
200V96820-0345 Multi-strap	200-10301-6161 Injector Inlet Pipe	202V27421-0263 Fuel Pressure Sensor	810W25424-0033 Wire Harness Assembly	WG9925550620 Primary Fuel Filter
				
WG1034121002 Injector	VG1038080007 Fuel Injector Assembly	200V10100-6126 Injector	200V10100-6127 Injector	200V06330-5041 Distribution Shell

HOWO TRUCK SPARE PARTS



曼发动机配件系列 MAN Engine Parts Series





HOWO TRUCK SPARE PARTS

曼发动机配件系列 MAN Engine Parts Series



200V26201-7199
Starter



VG1246090002
Starter



080V26201-7236
Starter



201V12501-7290
Fuel Filter Assembly



201V05000-7040
Oil Module



082V26101-7278
Generator



202V26101-7271
Generator



VG1095094002
Alternator



201V09411-5173
Intercooler Intake Pipe



200V06404-0083
Thermostat Housing



200V06302-0657
Coolant Elbow



201V06302-0643
Thermostat Outlet Pipe



201V09411-0664
Intake Elbow



202V15201-6188
Exhaust Brake Butterfly Valve



202V15201-6186
Exhaust Brake Butterfly Valve



202V09411-0868
Intercooled Intake Manifold



200V08102-0116
Front Row Manifold



200V08102-0234
Middle Exhaust Manifold



200V08102-0189
Rear Exhaust Manifold



WG9725478118
T7H Direction Machine



T7H 方向机
T7H Direction Machine




尿素液位传感器
Urea Level Sensor



WG9925550702
Oil Level Sensor



WG9925550004
Oil Level Sensor



201V06901-0192
Water Pump Seal